




CONSUMER ELECTRONICS

PHILIPS



AW 7890 AW 7892



(GB)	Stereo Radio Cassette Recorder	3
(F)	Radiocassette stéréo	7
(D)	Stereo-Radio-Cassetten-Recorder	11
(NL)	Stereo radio-cassetterecorder	15
(E)	Radiocasete estéreo	19
(I)	Radioregistratore stereo	23
(S)	Stereo kassettradio	27
(SF)	Stereo radionauhuri	31

(GB) English page 3

Illustrations pages 36-37
Guarantee and service pages 38-39-40

(F) Français page 7

Illustrations pages 36-37
Garantie et service après-vente pages 38-39-40

(D) Deutsch Seite 11

Abbildungen Seiten 36-37
Garantieleistung und Service Seiten 38-39-40
Amtsblatt Seite 51

(NL) Nederlands pagina 15


Abbeeldingen pagina's 36-37
Garantie en service pagina's 38-39-40

(E) Español página 19

Ilustraciones páginas 36-37
Garantía páginas 38-39-40

(MEX) México

NOM



NOM

Es necesario que lea cuidadosamente su instructivo de manejo.

(I) Italiano pagina 23

Illustrazioni pagine 36-37
Garanzia e servizio pagine 38-39-40

(S) Svenska sida 27

Figurer sidorna 36-37
Garanti och service sidorna 38-39-40

(SF) Suomi sivu 31

Kuvat sivut 36-37
Takuu ja huolto sivut 38-39-40

(DK) Danmark

Typeskiltet findes i batterirummet.

Dette produkt overholder kravene til radio-interferens af Europæisk Fællesmarked.

Bemærk: Netafbryderen POWER ① er sekundært indkoblet og afbryder ikke strømmen fra nettet. Den indbyggede netdel er derfor tilsluttet til lysnettet så længe netstikket sidder i stikkontakten.

Garanti og service sider 38-39-40

(N) Norge

Typeskilt finnes i batterirummet.

Observer: Netbryteren POWER ① er sekundært innkoblet. Den innebygde netdelen er derfor ikke frakoblet nettet så lenge apparatet er tilsluttet nettkontakten.

Garanti og service sider 38-39-40

For the illustrations, keep the pages 36-37 open

CONTROLS - figs. 1-2

- ① POWER on/off switch with indicator ✱
- ② DUBBING SPEED selector with high speed indicator ✱
- ③ FM STEREO indicator ✱
- ④ radio display, shows:
FM/MW/LW - the selected wave band (*LW not on all versions*)
the tuned frequency in 'MHz' (for FM) or 'kHz' (for MW and LW)
'1'...'5', indicating the PRESET location of the shown frequency
- ⑤ 'P1'...'P5' PRESET buttons - to select PRESET transmitters
- ⑥ MEMORY button - to store transmitter frequencies
- ⑦ radio TUNING buttons ▽ / △
- ⑧ PHONES socket for stereo headphones
- ⑨ FUNCTION selector - to select the sound source for reproduction or recording
- ⑩ FM MONO/STEREO selector
- ⑪ BAND selector
- ⑫ GRAPHIC EQUALIZER tone controls
100 Hz - lower bass
500 Hz - upper bass
3 kHz (3 000 Hz) - mid-range
5 kHz (5 000 Hz) - lower treble
12 kHz (12 000 Hz) - upper treble
- ⑬ BALANCE control
- ⑭ built-in mono microphone MIC
- ⑮ VOLUME control
- ⑯ tape counter with zero reset button, deck A
- ⑰ deck A keyboard, recording and playback
 - RECORD - record
 - ▶ PLAY
 - ◀◀ REWIND - fast rewind
 - ▶▶ F.FWD - fast forward wind
 - STOP/EJECT
 - ⏏ PAUSE
- ⑱ deck B keyboard, for playback only
 - ▶ PLAY
 - ◀◀ REWIND - fast rewind
 - ▶▶ F.FWD - fast forward wind
 - STOP/EJECT
 - ⏏ PAUSE
- ⑲ EXT. ANTENNA socket for FM-aerial (*not on all versions*)
- ⑳ CD/AUX sockets for recording from an amplifier, receiver, recorder, CD player, etc.
- ㉑ RIF-selector, for eliminating possible whistle tones during MW and LW radio recordings
- ㉒ VOLTAGE selector (*not on all versions*)
- ㉓ terminals for loudspeakers SPEAKERS

㉔ MAINS - socket for mains lead
The type plate will be found in the battery compartment.

SUPPLY

Battery supply

- Open the battery compartment (fig. 2).
- For the RADIO PRESET MEMORY (fig. 2), insert as indicated three batteries, type R6, UM3 or AA.
- For the radio cassette recorder, insert as indicated eight batteries, type R20, UM1 or D-cells (fig. 2).
- Remove the batteries if exhausted or if they will not be used again for a long period.
- The battery supply is switched off if the mains lead socket MAINS ㉔ is occupied. To change over to battery supply, pull out the plug from the MAINS socket ㉔.

Mains supply

- Check if the mains voltage as shown on the type plate corresponds to your local mains supply. If it does not, consult your dealer or service organisation.

If the set is equipped with a VOLTAGE selector ㉒, set this selector to the local mains voltage.

- Connect the mains lead to the MAINS socket ㉔ and the wall socket. The mains supply is now switched on.
- To disconnect the set from the mains completely, withdraw the mains plug from the wall socket.

Important note for users in U.K.:

When fitting a mains plug to the mains lead proceed as follows:
The wires in the mains lead are coloured in accordance with the following code: Blue = Neutral, Brown = Live.
These colours may not correspond with the colour markings identifying the terminals in your plug, so proceed as follows:
Connect the Brown wire to the terminal marked L or coloured Red.
Connect the Blue wire to the terminal marked N or coloured Black.
No connection is necessary to the earth terminal.
Note: This apparatus must be protected by a 3 Amp Fuse if a 13 Amp plug is used or, if any other type of plug is used, by a 5 Amp Fuse either in the plug or adaptor or at the distribution board. In doubt consult a qualified electrician.

CONNECTIONS

Stereo headphone socket ⑧ PHONES ⑧

You may connect stereo headphones with 3.5 mm plug to socket ⑧ PHONES ⑧. The loudspeakers are then muted.

Socket for FM-aerial ⑲ EXT. ANTENNA (Not on all versions)

Socket ⑲ is for connection of:

- a roof-mounted FM aerial with an impedance of 75 ohms
- the Cable or Community Antenna System, impedance 75 ohms

Input sockets CD/AUX 20

Cinch-sockets for amplifying or recording the signal from an amplifier, receiver, tuner, recorder, CD player, etc.

- Connect the CD/AUX sockets 20 to the output sockets TAPE OUT, REC OUT or LINE OUT of the other set.

Loudspeaker terminals 21 SPEAKERS

See fig. 4 for connecting the supplied loudspeakers (or others with an impedance of 8 Ohms). Connect the coloured (or marked) wire to the coloured terminal.

See fig. 3 for removing and fixing the supplied loudspeakers.

RADIO RECEPTION

- Switch on the set with POWER switch 1.
- Set the FUNCTION selector 9 to RADIO.
- Adjust the sound with the controls VOLUME 15, BALANCE 13 and GRAPHIC EQUALIZER 12.
- Select the wave band using the BAND selector 11. The radio display 4 shows the selected wave band 'FM', 'MW' (Medium Wave) or 'LW' (Long Wave) and the frequency in 'MHz' (for FM) or 'kHz' (for MW and LW). (LW not on all versions).
- For FM, pull out the telescopic aerial. To improve FM-reception, incline and turn the aerial. Reduce its length if the FM-signal is too strong (very close to a transmitter).
You may also push-in the telescopic aerial and connect an external FM-aerial with an impedance of 75 Ohms (or the Community or Cable Antenna system) to the EXT. ANTENNA socket 19 (not on all versions).
- For AM/MW and LW (Medium and Long Wave), the set is provided with a built-in aerial, so there is no need to use the telescopic aerial. The aerial can be directed by turning the whole set.
- In case of FM-reception, set the FM MONO/STEREO selector 10 to the desired position.
- Tune automatically, manually or by means of the PRESET-buttons 'P1'...'P5' to a radio station.

Automatic tuning

- Keep TUNING 7 ▽ or ▲ pressed until the displayed frequency keeps on changing; then release the button. The receiver stops when finding a strong transmitter.
- If the transmitter found is not the desired one, simply repeat this operation.

Manual tuning

Manual tuning is useful when you already know the frequency of the desired transmitter (e.g. from your programme guide).

- Keep TUNING 7 ▽ or ▲ pressed until you approach the required frequency.

- Then release the button and press it again quickly and briefly: then the displayed frequency stops.

- Then press TUNING 7 or ▲ briefly each time. In this way the frequency is changed step-by-step until finally the right frequency has been reached. One step is 0.05 MHz (50 kHz) on FM, 9 or 10 kHz on MW and 1 kHz on LW.

- When the FM STEREO indicator 3 ✱ lights up, you are receiving a FM-stereo transmitter. A disturbing noise, due to a weak FM-stereo signal, can be suppressed by setting the FM MONO/STEREO selector 10 to FM MONO. The FM STEREO indicator 3 ✱ will then go out and you will hear (and record) the FM programme in mono.

- Always switch off the set after use with POWER switch 1.

PREFERRED TRANSMITTERS - PRESET

For each wave band you can store the frequencies of 5 transmitters.

Storing transmitter frequencies

1. Select the wave band using the BAND selector 11.
2. Using the TUNING 7 ▽ ▲ buttons, tune either automatically or manually to the frequency to be stored. Programme guides often contain a list of transmitter frequencies.
3. If you want to store the frequency shown, press MEMORY 6.
4. Now, press the desired PRESET button 'P1'...'P5'. The chosen PRESET-location is shown on the display. The frequency is now stored.

- A stored frequency is only erased from the memory by storing another frequency in its place.
- The contents of the memory will be kept (also if the power supply is interrupted) until the RADIO PRESET MEMORY batteries (fig. 2) are exhausted.

Tuning to a preselected transmitter

- Set the FUNCTION selector 9 to RADIO.
- Select the wave band using the BAND selector 11.
- In case of FM-reception, set the FM MONO/STEREO selector 10 to the desired position.
- Press the desired PRESET button 'P1'...'P5'. The chosen PRESET-location is shown on the display.
- Always switch off the set after use with POWER switch 1.

CASSETTE RECORDER

Compact cassettes

For recording, use only NORMAL cassettes (ferric oxide, IEC type I).

For playback, any cassette type can be inserted.

Copyright

Recording is permissible insofar as copyright or other rights of third parties are not infringed.

For UK only: Recording and Playback of material may require consent. See Copyright Act 1956 and The Performer's Protection Acts 1958 to 1972.

Fast winding and rewinding

Press fast forward wind F.FWD ►► or REWIND ◄◄ button. To stop fast winding, press STOP button ■.

Safeguarding a cassette against erasure

Keep the cassette side to be safeguarded in front of you (fig. 6) and break out the left tab. Now, recording on this side is no longer possible.

You can render this safeguard ineffective by covering the aperture with a piece of adhesive tape.

Tape counter ⑮ - deck A

Set the tape counter ⑮ to zero by pressing the zero reset button immediately after inserting a cassette. By noting the counter reading at which each recording commences, you will be able to locate any of your programmes rapidly by fast winding or rewinding to the same reading.

RECORDING (on deck A only)

Preparation

During recording, the deck B buttons should not be pressed (except for PLAY ► during dubbing).

- Switch on the set with POWER switch ①.
- Set the DUBBING SPEED selector ② to NORMAL.
- Press EJECT ■ to open the cassette holder.
- Insert the cassette into deck A (fig. 5).

For recording you must use a NORMAL cassette (IEC type I) on which the tabs (fig. 6) are not broken out. At the very beginning of the tape, no recording will take place during the first 7 seconds when the leader tape passes the recorder heads.

- When monitoring during recording, adjust the sound with the controls VOLUME ⑮, BALANCE ⑬ and GRAPHIC EQUALIZER ⑫. These controls do not affect the recording.

Recording from the radio

- Set the FUNCTION selector ⑨ to RADIO.
- In case of FM radio recordings, set the FM MONO/STEREO selector ⑩ to the desired position.
- If a whistling sound occurs during MW or LW radio

recordings which was not present during normal radio reception, this sound can be suppressed by setting RIF-selector ⑭ to another position.

Mono recording from the microphone MIC ⑭

- Set the FUNCTION selector ⑨ to TAPE.
- Set the VOLUME control ⑮ to minimum (during microphone recordings, monitoring is not possible).

Recording from the CD/AUX sockets ⑳

- Set the FUNCTION selector ⑨ to CD/AUX.
- Connect the CD/AUX sockets ㉑ to the output sockets TAPE OUT, REC OUT or LINE OUT of the other set.

Starting and stopping

- Start recording by pressing RECORD ●; in doing so, PLAY ► is pressed too.
- For brief interruptions, press PAUSE II. To restart recording, press this button once more.
- To stop recording, press STOP ■. On pressing again, the cassette holder will open.
- Always switch off the set after use with POWER switch ①.

DUBBING - Copying from deck B to A

When copying, it is recommended to use fresh batteries or to connect the set to the mains supply.

- Switch on the set with POWER switch ①.
- Set FUNCTION selector ⑨ to TAPE.
- Set the DUBBING SPEED selector ② to: NORMAL for normal speed copying; HIGH for high speed copying.

Do not switch this selector during dubbing.

- Press both EJECT buttons ■ and insert a recorded cassette into deck B and a cassette which is suited for recording into deck A (fig. 5).
- Dubbing will start by pressing at the same time on deck B PLAY ► and on deck A RECORD ●. During high speed dubbing, the indicator ② ✨ lights up.
- By pressing PAUSE II on deck A, you can omit undesired passages while deck B continues, or you can insert another cassette in deck B and search for a particular passage on it. To restart copying, press PAUSE II once more.
- Using PAUSE II of deck B, deck A will record a blank part.
- To stop dubbing, press both STOP buttons ■.
- Always switch off the set after use with POWER switch ①.

CASSETTE PLAYBACK

Playback on deck A or B

- Switch on the set with POWER switch ①.
- Set FUNCTION selector ⑨ to TAPE.
- Press EJECT ■ and insert a recorded cassette (fig. 5).

- Adjust the sound with the controls VOLUME (15), BALANCE (13) and GRAPHIC EQUALIZER (12).
- Press PLAY ► and playback will start.
- To stop playback, press STOP ■.
- Always switch off the set after use with POWER switch (1).

Continuous play (estafette)

- Switch on the set with POWER switch (1).
- Set FUNCTION selector (9) to TAPE.
- Press both EJECT buttons ■ and insert a recorded cassette into both decks (fig. 5).
- Press on deck B PLAY ► and on deck A PAUSE II and PLAY ►: deck B will now play and deck A stands still.

As soon as deck B stops (at the end of the cassette or when its STOP button ■ is pressed), PAUSE II is released and deck A will start playing back.

- To stop playback, press STOP ■.
- Always switch off the set after use with POWER switch (1).

MAINTENANCE

Cassette decks

To ensure a good recording and playback quality, clean the parts indicated in fig. 7 after every 50 hours of operation or, on average, once a month.

- Open the cassette holder by pressing EJECT ■.
- Use a cotton bud slightly moistened with alcohol or a special head cleaning fluid.
- Press PLAY ► and clean the rubber pressure roller (D) (fig. 7).
- Then press PAUSE II and clean the capstan (C), recording/playback head (B) and erase head (A).
- After cleaning, press STOP ■.

Cleaning of the heads (A) and (B) can also be done by playing the cleaning cassette SBC 114 through once as an ordinary cassette.

Notes

- The recorder-mechanisms are fitted with self-lubricating bearings and therefore must not be oiled or greased.
- Do not expose the set, batteries and cassettes to rain, moisture, sand, or to excessive heat from e.g. heating equipment or in motor cars parked in the sun.
- Fingerprints, dust and dirt on the apparatus can be removed using a soft and clean, slightly damp leather cloth. Do not use any cleaning agents which contain abrasives or solvents such as benzine thinner, alcohol, refined petrol or ammonia, since they may affect and harm the cabinet.

This product complies with the radio interference requirements of the European Community.

GARANTI I SVERIGE

Garanti lammas på denna Philipsapparat i enlighet med den garanti förbindelse som tillhandahålls av återförsäljaren. I garanti förbindelsen ges anvisningar om reklamation. Garantin gäller endast i inköpslandet.

TAKUU JA HUOLTO

Tämän tuotteen rakenne on pitkäaikaisen, kokemuksella tehdyn tutkimustyon tulos. Jatkuvan erittoutantovaiheissa tehtävän laatu tarkkailun vuoksi Philips takaa tuotteensa laadun. Tarkemmat tiedot takuuehdoista saat Philips-myyjältä tai alla olevasta osoitteesta.

Philips AB, Siniikalliontie 3, 02630 ESPOO - ☎ (358-0)-50261
 Oy Philips AB, P.O. Box 75, 02631 ESPOO

GARANTÍA PARA MÉXICO

Este aparato está fabricado con materiales de alta calidad y ha sido cuidadosamente verificado. Philips, por lo tanto, da a usted una garantía de 12 meses a partir de su fecha de compra. La garantía ampara la reposición de las piezas defectuosas debidas a fallas en su montaje o en los materiales, incluyendo la mano de obra necesaria para su reemplazo en nuestras Sucursales o talleres autorizados.

En caso de fallas en su aparato le rogamos se sinva poner en contacto con su distribuidor.

Esta garantía no cubrirá las averías que resulten como consecuencia de una instalación incorrecta del aparato, manifiesto maltrato o uso inadecuado del mismo.

Philips se obliga a reparar y devolver a usted su aparato en un plazo no mayor de 30 días hábiles contados a partir de la fecha de haber ingresado su aparato a uno de nuestros talleres. Para que esta garantía sea válida, es necesario que el certificado que figura en la parte posterior de este instructivo haya sido debidamente llenado en el momento de la compra del aparato.

En caso de extravío del certificado con la presentación de la factura o remisión de su aparato podrá hacer efectiva la garantía correspondiente.

Si usted tiene alguna duda o pregunta que no le pueda solucionar su distribuidor, por favor ponerse en contacto con:

Oficinas Centrales de Servicio
 Av. Coyoacán No. 1051, Col. del Valle
 03100 MEXICO, D.F. - ☎ 5-75-20-22 o 5-75-01-00

CONDIÇÕES VÁLIDAS PARA PORTUGAL

A Philips Portuguesa, SA, assegura ao comprador deste aparelho garantia contra qualquer defeito de material ou fabrico, pelo prazo de 6 meses, contado a partir da data de aquisição. As agulhas de fonocaptores não têm qualquer garantia.

A Philips Portuguesa, SA, anula a garantia ao aparelho desde que se verifique ser a deficiência motivada por acidente, utilização incorrecta, causas externas, ou nos casos em que apresente vestígios de ter sido violado, ajustado ou reparado por entidade não autorizada. Também será considerada nula a garantia se este certificado apresentar rasuras ou alterações.

A Philips Portuguesa, SA, obriga-se a prestar a garantia referida somente nos seus Serviços Técnicos ou nos Concessionários de Serviço autorizados. As despesas e riscos de transporte de e para as oficinas serão sempre da responsabilidade do comprador.

Nota: Para que o aparelho seja assistido ao abrigo da garantia, é indispensável que seja apresentado este certificado, devidamente preenchido e autenticado, por vendedor autorizado, aquando da sua aquisição.

Se sobre esta garantia necessitar algum esclarecimento que o vendedor não lhe possa dar, deve dirigir-se a:

Philips Portuguesa, SA,
 - Outurela - Camaxido - 2795 LINDA A VELHA - ☎ 218 00 71/9
 - R. Eng. Ezequiel de Campos, 182 - 4100 PORTO - ☎ 67 26 13

Η ΕΓΓΥΗΤΗΣ ΕΙΣ ΤΗ ΣΕΡΒΙΣΙΑ ΚΑΙ ΕΠΙΤΥΧΙΑ ΣΤΗΝ ΕΛΛΑΔΑ

Η φωνητική μηχανή που αγοράσατε, η οποία για τις ελλήνες αποτελεί και τον πιο αξιολογικό εξοπλισμό της οικίας, έχει κατασκευαστεί με μεγάλη προσοχή. Αν όμως, παρά όλα αυτά, κάποιο ελάττωμα υπήλκυσε, το ελάττωμα αυτό και η φωνητική μηχανή που αγοράσατε, σύμφωνα με την Εγγύηση της Ηλεκτρονικής Εργασίας, επιστρέφεται για επανόρθωση ή αντικατάσταση, ανάλογα με το είδος του ελαττώματος. Η Εγγύηση ισχύει για ένα χρόνο από την ημερομηνία αγοράς.

Η Εγγύηση ισχύει για τη φωνητική μηχανή που αγοράσατε, σύμφωνα με τις προϋποθέσεις που αναφέρονται στην Εγγύηση.

α) Για να αποκτήσει ο αγοραστής το δικαίωμα της Εγγύησης, πρέπει να συμπληρώσει το φέρων της Εγγύησης, να το υποβάλει στο κατάστημα από το οποίο αγοράστηκε η φωνητική μηχανή και να τηρείται η Εγγύηση.

β) Για να αποκτήσει ο αγοραστής το δικαίωμα της Εγγύησης, πρέπει να συμπληρώσει το φέρων της Εγγύησης, να το υποβάλει στο κατάστημα από το οποίο αγοράστηκε η φωνητική μηχανή και να τηρείται η Εγγύηση.

γ) Όταν ο αγοραστής κοιτάσει την Εγγύηση, πρέπει να τηρείται η Εγγύηση.

δ) Για να αποκτήσει ο αγοραστής το δικαίωμα της Εγγύησης, πρέπει να συμπληρώσει το φέρων της Εγγύησης, να το υποβάλει στο κατάστημα από το οποίο αγοράστηκε η φωνητική μηχανή και να τηρείται η Εγγύηση.

Μετά τη λήξη του χρόνου Εγγύησης, για κάθε επανόρθωση, αντικατάσταση ή επιστροφή, ο αγοραστής θα πληρώσει το κόστος μεταφοράς, σύμφωνα με τις προϋποθέσεις που αναφέρονται στην Εγγύηση.

Αντιπροσωπεία Κεντρικών ΣΕΡΒΙΣ PHILIPS:
 25ης Μαρτίου 15, 177 78 Ταΐπος - ☎ 4894.911
 Τηλεφωνία 62, 546 93 Ουσσαλονίκη - ☎ 260.621

Guarantee certificate

Garantieschein

Certificado de garantía

Certificado de garantia

Takuutodistus

Certificat de garantie

Identificatiekaart

Certificado di garanzia

Garantibevist

Εγγύηση

Type no. of product

Tipo no. del producto

Date of purchase - Date d'achat - Kaufdatum - Koopdatum
 Fecha de compra - Data da compra - Data di acquisto - Kobodato
 Kjøpedato - Inkopsdato - Ostapawa - Ημερομηνία αγοράς

19

Dealer's name, address and signature

Nom, adresse et signature du revendeur

Name, Anschrift und Unterschrift des Händlers

Naam, adres en handtekening van de handelaar

Nombre, dirección y firma del distribuidor

Nome, indirizzo e firma del fornitore

Nome, morada e assinatura do vendedor



Forhandlerens navn, adresse og underskrift




Återförsäljarens namn, adress och namnteckning

Myyjän nimi, osoite ja allekirjoitus

Όνομα/Επώνυμο Αντιπροσώπου

08-89





tolzt
flers
rab
pne-
dt
ster-
Ver-
ndo
me,
lder
vor-
sch-
vor,
zu-
und
zu-
zu-

—
do
act
bra
tros
act
del
to a
do
elio
cion
ato,
para
ent a
esto
tura
con
nos

—
100
ed i
foyl
on
act-
—
on
está
act
ndo
n qu
D
'89

GUARANTEE AND SERVICE FOR UNITED KINGDOM

Philips sell this product subject to the understanding that if any defect in manufacture or material shall appear in it within 12 months from the date of consumer sale, the dealer from whom the product was purchased will arrange for such defect to be rectified without charge, provided

1. Reasonable evidence is supplied that the product was purchased within 12 months prior to the date of claim
2. The defect is not due to use of the product for other than domestic purposes, or on an incorrect voltage, or contrary to the Company's operating instructions, or to accidental damage (whether in transit or otherwise), misuse, neglect or inexperienced repair

Products sent for service should be adequately packed as no liability can be accepted for damage or loss in transit, and name and address must be enclosed

Facts about free service

When service is required, apply to the dealer from whom the product was purchased. Should any difficulty be experienced in obtaining Service, e.g. in the event of the dealer having ceased to trade, you are advised to contact Philips Service

These statements do not affect the statutory rights of a consumer.

If you have any questions which your dealer cannot answer, please write to **Philips Consumer Relations,**

PO Box 298, 420 London Road, CROYDON CR9 3QR,
or **(01) 689-2166 Consumer Advice.**

Please retain this card. Produce if service is required

GUARANTEE AND SERVICE VALID FOR IRELAND

This apparatus is made of high quality material and great care has been taken in its manufacture

Philips, therefore, give you a guarantee on parts against failures arising from faulty workmanship or material for 12 months after date of purchase. This guarantee is valid on the condition that this certificate is completed and signed immediately on delivery of the apparatus. In case of failure ask your dealer for further information

If you have any questions which your dealer cannot answer, you may apply to **Philips Electrical (Ireland) Ltd., Service Department,**
Newstead, Clonskeagh, DUBLIN 14 - ☎ 69 33 55

GUARANTEE AND SERVICE VALID FOR AUSTRALIA

The benefits given to the purchaser by this warranty are in addition to all other rights and remedies, which, under the Trade Practices Act or other Commonwealth or State law, the purchaser or owner has in respect of the product

The Philips product carries the following warranties:

Compact Disc Players 12 months Home Audio Systems 6 months
Clock radios, portable radios, cassette recorders, cassette players and radio recorders 90 days

Any defect in materials or workmanship occurring within the specified period from the date of delivery, will be rectified free of charge by the retailer from whom this product was purchased

Note: Please retain your purchase docket to assist prompt service

Conditions of this warranty

1. All claims for warranty service must be made to the retailer from whom this product was purchased. All transport charges incurred in connection with warranty service or replacement will be paid by the purchaser

2. These warranties do not cover batteries and extend only to defects in materials or workmanship occurring under normal use of the product where operated in accordance with our instructions

Philips Consumer Products Division, Technology Park, Figtree Drive, Australia Centre, HOMEBUSH 2140, New South Wales

GUARANTEE AND SERVICE FOR NEW ZEALAND

Thank you for purchasing this quality Philips product. The document you are now reading is your guarantee card

Guarantee

Philips New Zealand Ltd guarantees this product against defective components and faulty workmanship for a period of **12 months** from the date you bought it. If the product breaks down during the guarantee period, Philips shall - subject to the following conditions - repair or replace the product at **no charge to you**. This includes costs for labour, parts, and cartage

Conditions

1. The product must have been purchased in New Zealand, and this guarantee card completed at time of purchase (this is your proof of the date of purchase)

2. The guarantee applies only to faults caused by defective components, or faulty workmanship on the part of the manufacturer

3. The guarantee does not cover failures caused by misuse, neglect, normal wear and tear, accidental breakage, use on the incorrect voltage, use contrary to operating instructions, or unauthorised modification to the product or repair by an unauthorised technician

4. Reasonable evidence (in the form of a sales docket or completed guarantee card) must be supplied to indicate that the product was purchased no more than 12 months prior to the date of your claim

5. In the event of a failure, Philips shall be under no liability for any injury, or any loss or damage caused to property or products other than the product under guarantee

This guarantee does not prejudice your rights under common law and statute, and is in addition to the normal responsibilities of the retailer and Philips.

How to claim

Should your Philips product fail within the guarantee period, please return it to the retailer from whom it was purchased. In most cases the retailer will be able to satisfactorily repair or replace the product. However, should the retailer not be able to conclude the matter satisfactorily, or if you have other difficulties claiming under this guarantee, please contact **The Guarantee Controller, Philips New Zealand Ltd, PO Box 1041, AUCKLAND - ☎ (09) 605-914**

GARANTIE FÜR DIE BUNDESREPUBLIK DEUTSCHLAND UND WEST-BERLIN

Philips-Geräte sind Markenartikel, die mit größter Präzision nach modernsten Fertigungsmethoden und mit einem Höchstmaß an Sorgfalt hergestellt werden. Das Gerät wird Ihnen gute Dienste leisten, vorausgesetzt daß Sie es sachgemäß bedienen und unterhalten. Trotz aller Sorgfalt ist das Auftreten von Fehlern nicht auszuschließen. Ihr Partner für die Behebung derartiger Fehler ist Ihr Fachhändler, bei dem das Gerät erworben wurde. Falls ein Reklamationsfall eintritt, wenden Sie sich bitte unter Vorlage des Einkaufsbeleges und des Gerätepasses an Ihren Fachhändler

GARANTIE ET SERVICE APRÈS-VENTE EN FRANCE

Cet appareil a été fabriqué avec le souci de vous donner entière satisfaction. PHILIPS fournira gratuitement au vendeur les pièces détachées nécessaires à sa réparation pendant les périodes suivantes, chacune prenant effet à compter de la date de vente:

- 6 mois pour les magnétophones à cassettes portatifs, les récepteurs radio portatifs, les radiocassettes et les radio-réveils
- 12 mois pour les radiocassettes équipées de la fonction Compact Disc et les baladeurs Compact Disc
- 12 mois pour les appareils entrant dans la composition d'une chaîne électro-acoustique, y compris les chaînes compactes stationnaires équipées d'au moins deux sources sonores;

sauf si la détérioration résulte d'une cause étrangère à l'appareil ou du non respect des prescriptions d'utilisation.

Vous bénéficierez en tout état de cause des dispositions des art 1641 et suivants du Code Civil relatifs à la garantie légale

Pour tout conseil ou intervention, adressez-vous à votre vendeur. Pour tout renseignement complémentaire, vous pouvez vous adresser à la succursale Philips la plus proche.

Soucieux d'améliorer continuellement la qualité de nos produits, nous nous réservons le droit d'en modifier à tout moment les caractéristiques

PHILIPS Électronique Domestique - Société en nom collectif
RCS NANTERRE B 333 760 833

64, Rue Camot - ☎ B.P. 306 - 92 156 SURESNES Cédex
Informations Consommateurs: ☎ (16-1) 42 04 25 60

GARANTIE EN BELGIQUE ET LUXEMBOURG

Pour les conditions de garantie en Belgique et Luxembourg veuillez vous référer à la carte de garantie que le revendeur doit vous remettre au moment de l'achat

● Pour la Belgique

Si après l'achat de l'un ou l'autre appareil Philips vous avez des problèmes concernant par exemple la garantie, le fonctionnement ou l'utilisation de ces appareils et que le distributeur qui vous a vendus ces appareils éprouve des difficultés pour les résoudre, prenez contact, soit par téléphone, soit par écrit avec notre service

'Contact Clientèle', Place de Brouckère 2, 1000 - BRUXELLES
☎ 02/211 91 11

GARANTIE EN SERVICE IN BELGIË EN LUXEMBURG

In België en Luxemburg gelden uitsluitend de garantiebepalingen zoals die in het via uw handelaar apart verstrekte garantieboekje staan aangegeven

● Voor België

Indien u na de aankoop van een of ander Philips apparaat problemen heeft met bijv. de vaarborg, de werking, of het gebruik ervan, en indien de verdeler die u deze apparaten verkocht heeft moeilijkheden ondervindt om deze problemen op te lossen, stelt u zich dan telefonisch of schriftelijk in verbinding met onze dienst

'Klanten Kontakt', de Brouckereplein 2, 1000 - BRUSSEL
☎ 02/211 91 11

GARANTIE EN SERVICE IN NEDERLAND

• Wat wordt gegarandeerd?

Philips Nederland garandeert dat dit apparaat kosteloos wordt hersteld indien - bij normaal particulier gebruik volgens de gebruiksaanwijzing - binnen 12 maanden na aankoopdatum fabricage- en/of materiaalfouten optreden.

• Wie voert de garantie uit?

De zorg voor de uitvoering van de garantie berust bij de handelaar die u het apparaat verkocht heeft. De handelaar kan daarbij eventueel een beroep doen op een der Philips Technische Service Centra.

• Uw aankoopbon + de identificatiekaart

De identificatiekaart is uw garantiebewijs. U kunt alleen een beroep doen op de bevoegdigheden van de garantie tegen overlegging van de aankoopbon (factuur, kassabon of kwitantie), in combinatie met de identificatiekaart, waarop typenummer en serienummer zijn vermeld. Uit de aankoopbon dienen duidelijk de aankoopdatum en de naam van de handelaar te blijken. Mocht het noodzakelijk zijn deze documenten aan uw handelaar af te geven, dan kunt u hem daarvoor een ontvangstbewijs vragen. De garantie vervalt indien op de genoemde documenten iets is veranderd, doorgehaald, veranderd of onleesbaar gemaakt, waarop typenummer en serienummer zijn vermeld, doorgehaald, veranderd of onleesbaar gemaakt.

• Hoe te handelen bij een storing?

Om onnodige kosten te voorkomen, raden wij u aan bij storingen eerst nauwkeurig de gebruiksaanwijzing te lezen. Indien de gebruiksaanwijzing daarin geen uitkomst biedt, kunt u uw handelaar raadplegen en/of hem het apparaat ter reparatie in de werkplaats aanbieden.

• ...en bij problemen?

Bij problemen omtrent de garantie-uitvoering kunt u zich in verbinding stellen met **Philips Nederland, Afdeling Consumentenbelangen, Antwoordnummer 500 - 5600 VB EINDHOVEN** (postzegel niet nodig), of ☎ **040-78 11 78**.

GARANTIE FÜR DIE SCHWEIZ

Philips-Geräte sind aus einwandfreiem Material und mit großer Sorgfalt hergestellt worden. Dieses Gerät wird Ihnen gute Dienste leisten, sofern es sachgemäß bedient und unterhalten wird. Trotz aller Sorgfalt ist das Auftreten von Fehlern nicht ganz auszuschließen. Im Falle eines Defektes wenden Sie sich bitte unter Vorlage des Einkaufsbeleges und des Gerätepasses an das Fachgeschäft, in welchem Sie das Gerät erworben haben.

GARANTIE POUR LA SUISSE

Les appareils Philips ont été fabriqués au moyen de matériaux de toute première qualité et avec beaucoup de soins. Cet appareil vous donnera encore plus de satisfaction si l'utilisation et l'entretien sont suivis selon le mode d'emploi. Malgré tous les soins apportés, l'apparition de défauts n'est pas exclue. Dans ce cas, nous vous serons reconnaissants de bien vouloir vous adresser directement chez votre vendeur muni du passeport de l'appareil ainsi que de la facture s'y reportant.

GARANZIA PER LA SVIZZERA

Gli apparecchi Philips sono prodotti con materiali di prima qualità e assemblati con la massima cura. Essi Vi offriranno un ottimo servizio, in cambio di un accurato uso e manutenzione. Malgrado tutti i nostri sforzi, non è escluso che possano avvenire dei guasti. In caso di difetto Vi preghiamo di rivolgervi al Vostro fornitore specializzato, portando con Voi il passaporto assieme ai documenti d'acquisto.

GARANZIA E ASSISTENZA VALIDE PER L'ITALIA

Questo apparecchio è stato realizzato con materiali di prima qualità e costruito con la massima cura. La Philips comunque fornisce all'acquirente una Garanzia di buon funzionamento secondo le condizioni stabilite dall'ANIE.

Tale Garanzia decorre dalla data di acquisto ed ha la durata di **6 mesi**. Per aver diritto alla Garanzia è necessario che questo certificato riporti i dati di Modello e Matricola dell'apparecchio, la data di acquisto ed il timbro del rivenditore, inoltre per tutti gli apparecchi per i quali è prevista la "ricevuta fiscale" (o altro documento di consegna) il documento stesso dovrà essere conservato con questo certificato a certificazione della data d'acquisto.

In caso di necessità il prodotto dovrà essere fatto pervenire al Centro di Assistenza più vicino al cui recapito è pubblicato sugli elenchi telefonici della zona di residenza alla voce Philips. Per questo apparecchio Philips offre un Abbonamento all'Assistenza Tecnica. Per informazioni rivolgersi ai Centri di Assistenza o al servizio Consumatori Philips.

Philips S.p.A., Viale le Fulvio Testi 327, 20162 MILANO
☎ **1678-20026**

GARANTIE IN ÖSTERREICH

Die Österreichische Philips Industrie Gesellschaft m.b.H. unterstützt die gesetzlichen Gewährleistungsverpflichtungen ihres Handels durch folgende Garantiezusage:

1. Dieses Gerät (siehe Typenschild) wird innerhalb von 6 Monaten ab Verkaufsdatum bei Auftreten eines Funktionsmangels (Fabrikations- oder Materialfehler) in einer unserer Service-Philialen kostenlos, d.h. ohne Berechnung von Material und Arbeitszeit, repariert.
2. Die Garantiezusage betrifft nur Neugeräte, die über die Österreichische Philips Industrie Gesellschaft m.b.H. und ihre Vertragspartner in Österreich verkauft wurden. Sie gilt für folgende Arten: Cassetten-Rekorder, Compact Disc-Spieler, HiFi-Basistone, HiFi-Kombinationen, Musik-Clocks, Plattenspieler, Rad-o-Rekorder und das mitgelieferte Originalzubehör d. eser Geräte.

3. Zur Inanspruchnahme einer Garantiereparatur gemäß der vorliegenden Zusage sind dieser Garantieschein und die Originalrechnung mit Kaufdatum vorzulegen.

4. Anstelle einer kostenlosen Garantiereparatur behalten wir uns vor, das defekte Gerät gegebenenfalls gegen ein Neues auszutauschen.

5. Schäden, die durch äußere Einflüsse, unsachgemäße Behandlung oder unsachgemäßen Fremdeingriff entstanden sind, sowie Gebrauchsfehler oder Glasbruch sind von dieser Garantiezusage ausgeschlossen.

Philips Zentrale Kundeninformation:

- 1101 WIEN, Trieserstraße 64, ☎ 0222-60101-DW 1620 oder DW 1563
- 6020 INNSBRUCK, Klöstergasse 4, ☎ 05222-74694
- 9020 KLAGENFURT, Villacher Straße 161, ☎ 0463-22397-DW 94
- Philips Service-Organisation:
- 1232 WIEN, Ketzergasse 120, ☎ 0222-8662-0

PHILIPS IBÉRICA, S.A.E.

Garantía este aparato durante 6 meses, a partir de la fecha de adquisición, de la forma siguiente:

1. Cubriendo cualquier defecto de fabricación o vicio de origen, así como la totalidad de sus componentes, incluido el mano de obra necesario para el reemplazo de las piezas defectuosas, por nuestros talleres autorizados.
2. Esta garantía no cubrirá la avería, si es consecuencia de incorrecta instalación del aparato, maltrato o uso inadecuado del mismo. La calificación de las averías corresponderá únicamente a los servicios técnicos de los talleres autorizados Philips.
3. Las reparaciones que pudieran producirse durante el periodo de vigencia de la presente garantía se efectuarán, bien en el domicilio del usuario, bien en los talleres autorizados Philips, a libre elección y dentro de ésta último.
4. Transcurrido un mes desde la fecha de adquisición del aparato, todos los gastos de desplazamiento del personal técnico para proceder al examen y/o reparación del aparato correrán por cuenta del usuario de acuerdo con las tarifas establecidas para este concepto.
5. En todas las reparaciones se deberá acompañar al aparato factura de compra y la presente garantía debidamente cumplimentada, con la indicación exacta de la fecha de venta del aparato.
6. En todo caso, el titular de la garantía tiene los derechos mínimos reconocidos por la Ley.

Titular (Comprador)

Domicilio

GARANTI OG SERVICE FOR DANMARK

De er nu ejer af et apparat, hvis konstruktion er baseret på erfaring og lang tids forskning. Philips garanterer for kvaliteten, og hvert led i fabrikationen er underlagt stadig kontrol. Alle hændelser om fejl under garantien skal rettes til den forhandler, der har udsættet og underskrevet garantibrevet, h. v. p. de gældende garantibestemmelser tillige er anført. Garantien er kun gældende i købslandet.

GARANTI I NORGE

De er nå eier av et apparat som er basert på lang tids forskning og erfaring. Philips garanterer for kvaliteten, men hvis en feil skulle oppstå bes. De ta kontakt med den forhandler som har utlevert og underskrevet garantibrevet. Garantien gjelder kun i kjøpslandet, h. v. de gjeldende garantibestemmelser må følges.

Hvis De trenger ytterligere opplysninger utøver de forhandleren kan gi Dem, kan De henvende Dem til **Norsk A/S Philips, Adv. Audio/Video, Sandstuveien 70, OSLO 6 - ☎ 02 - 62 02 00**